

# How fast do pits and septic tanks fill up? Implications for design and maintenance

UKZN: Kitty Foxon, Chris Buckley,  
Chris Brouckaert, Babatunde Bakare

PID: Dave Still, Frances Salisbury




UNIVERSITY OF  
KWAZULU-NATAL

INYUVESI  
YAKWAZULU-NATALI


# Mass Balances: An introduction to basic Chemical Engineering

- Matter cannot be created or destroyed



$$\text{Accumulation} = \text{Inflow} - \text{Reaction} - \text{Outflow}$$

# Application to pit latrines



## • Inflow:

- Urine and faeces
- Anal cleansing material
- Cleaning water, detergents, disinfectants, rubbish

## • Reaction

- Biodegradable material = Food
- $\text{Food} + \text{O}_2 \rightarrow \text{BUGS} + \text{CO}_2$
- $\text{Food (no O}_2) \rightarrow \text{bugs} + \text{CH}_4$   
(methane)

## • Outflow:

- Continuous drainage to surroundings
- Water and dissolved components


- Accumulation =  
Inflow – reaction – outflow



# Mass balance in pits cont.

- So accumulation is due to
  - BUGS
  - bugs
  - Salts
  - non-degradable material (including rubbish)
  - Some undegraded, but potentially biodegradable material

# Application to septic tanks



## Refraction:

- Similar to pit *but*
- More water
- More rubbish (usually)
- degradation
- More detergent

## Accumulation:

- Scum (degrades slowly)
- Similar to pit *but*
- bugs
- More water
- Unbiodegradable
- Solids can leave too
- material
- Some potentially biodegradable material



# Accumulation rate calculations:

- Rate at which material is added
  - Average excreta production per person per day
    - Faeces  $\sim 0.12 - 0.40 \text{ l /d}$
    - Urine  $\sim 0.6 - 1.5 \text{ l /d}$
  - Average addition per person per year
    - Faeces =  $0.3 \text{ l /d} \times 365 \text{ d/year} = 110 \text{ l /ca.year}$
    - Urine =  $1.2 \text{ l /d} \times 365 \text{ d/year} = 440 \text{ l /ca.year}$
  - Total volume added:  $550 \text{ l /person.year}$

# Accumulation rate in pit latrines: Data

- Faeces added  $\pm 110 \ell$  /person.year
- Measured solids accumulation rates:

Solids content:  
approx 330g/kg

Study area	Filling rate [ $\ell$ /person.year]	Reference
Soshanguve	24	Norris (2000)
Philippines	40	World Health Organisation (1958)
Besters Camp (eT Muncip.)	<20 to >80 (70)	City of Durban
Mbazwana (northern KZN)	10 to 78 (25)	Partners in Development
Limpopo	43	Tsonang NGO
Mafunze	11 to 146 (48)	Partners in Development
Ezimangweni (eT Muncip.)	27 $\pm$ 10	UKZN
Savana Park (eT Muncip.)	31 $\pm$ 21	UKZN
Folweni (eT Muncip.)	44 $\pm$ 46	UKZN


Don't forget toilet paper!

# Accumulation in pit latrines: Mass balance

- Less sludge accumulates than the amount of faeces added
  - (even ignoring rubbish and toilet paper!)
- i.e. A significant amount of solids reduction occurs in the pit
- The solids reduction is predominantly due to biological action
- Liquid mostly leaves the pit through pit walls



# Sludge accumulation rate vs. no. of users



# Accumulation rate in Septic tanks: Data

- Faeces added  $\pm 110\ell/\text{person}\cdot\text{year}$
- Measured solids accumulation rates:

Solids content:  
approx 30g/ $\ell$

Filling rate [ $\ell/\text{person}\cdot\text{year}$ ]	Comment	Reference
64 - 92	Decreases with time	Gray (1995)
50	Decreases slightly with time	Bounds (1995)
69		PHS (1949)
64		Moore (2000)
76		Pradhan (2007)
69-106	Decreases with septic tank size	Brandes (1978)

# Comparison between pit latrines and septic tanks

- Cannot compare rates in  $\ell$ /person.year since septage is much *wetter* (more water) than pit latrine sludge
  - Using some rough density values
    - Pit sludge = 1.5 kg/ $\ell$
  - Using limited solids content data from literature
    - Pit sludge = 330 g Solids/kg
    - Septage = 30 g Solids/L
  - Gives average (dry) solids accumulation rates of
- Pit sludge = 19 kg dry solids/person.year
- Septage = 2 kg dry solids/person.year

# Summary: pit filling rates

- Pit latrines:
  - Wide range of numbers observed in field
    - 40ℓ/person.year seems a reasonable mean
    - 60ℓ/person.year reasonable figure for design
  - Accumulation rate *decreases* with number of users
  - Accumulation rate *decreases* as pit fills (rate of filling slows with time)

# Summary: Septic tank filling rates

- Septic tanks:
  - Wide range of numbers observed in field
    - 60ℓ/person.year seems a reasonable mean
    - 80ℓ/person.year reasonable figure for design
  - Greater volumes of sludge generated than in pit latrines, but solids content is much less (10%).
  - Accumulation rate *decreases with time*

# Removed sludge

- In both cases, the sludge is fairly well stabilised (little residual biodegradability)
- Should not be put into WWTP!

# Helminth eggs

- Most human pathogens (virus, bacteria) are deactivated in pit latrines and septic tanks
- Helminth eggs are the most persistent
- UKZN/PID studies on *Ascaris* egg viability in exhumed pit latrine sludge

# Helminth eggs in pit sludge - results

- Total egg counts: 0 – 3500 eggs/g sludge
- % of eggs possibly viable: 0-96%
- % of eggs with visible larva: 0-40%
- % of eggs definitely infectious: 0-9%  
– (motile larva)
  
- Material from *emptied pits* therefore  
average age >5 years





# Helminth eggs in septage

- Literature indicates values between  $10^2$  and  $10^3$  eggs/g sludge
- *Indicates that long residence in a pit latrine or septic tank does not deactivate helminth eggs*

# Filling rates: implications for design

- Design around maintenance programme:
- Approach (1)
  - Design for government/municipal/NGO emptying programme (householder not responsible)
  - $t$  = Frequency of emptying (e.g. 10 years)
  - $r$  = Design filling rate (e.g. 60ℓ/person.year)
  - $n$  = Average number of users in household (e.g. 6 people)
- Design equation: Pit volume =  $V = r \times n \times t$   
e.g. 
$$\begin{aligned} V &= 60\ell/\text{person}\cdot\text{year} \times 6 \text{ people} \times 5\text{years} \\ &= 3\,000 \ell \\ &= 3 \text{ m}^3 \end{aligned}$$



# Filling rates: implications for design

- Design around maintenance programme:
- Approach (2)
  - Large pits are difficult to empty
  - Require *professional* emptiers
  - Require specialised equipment
  - 100% risk of helminth infection
- Therefore, if no local capacity for organised emptying programme, build shallow pits that can be emptied by householder.
- Or, if high capacity for organised emptying programme, build shallow pits that can be quickly emptied with reduced risk of helminth infection.



# Design of septic tanks

- More complicated since design includes
  - Sludge accumulation
  - Liquid flow
- Many standard design texts
- Bigger tanks require less frequent desludging.

# What next?

1. What do you do with the emptied pit contents?
2. Improved design, better operation requires better understanding of what happens in pit latrines.

# Acknowledgements

- Water Research Commission
- eThekweni Municipality